

## 95 Extra Tack Carpet Adhesive

**Roberts 95 Extra Tack Carpet Adhesive is water-based and specifically formulated to provide a tacky film of adhesive that is strong enough to eliminate any movement in the carpet after the installation is completed. It is suitable for both Double Bond and Direct Stick installations. Roberts 95 Carpet Adhesive is designed to be used for bonding both slab underlay to the subfloor and the carpet to the slab underlay. It is suitable for adhering all tufted and woven carpets except fusion bonded carpets, together with Textron™ paper, woven polypropylene and jute sided latex foam laminated slab underlays.**

**The adhesive offers a quick grab and a shorter working time for smaller installations because the adhesive tacks up more quickly and has excellent rebonding for hard to hold carpets.**

### Surface Preparation

To be in accordance with the Australian Standard 2455.1:2007 "Textile floor covering – installation practice". All surfaces to be bonded shall be dry, smooth, sound and clean. Subfloors must also be free of wax, grease and hydrostatic pressure. The minimum subfloor temperature before commencing surface preparation and adhesive application is 10 °C. It is recommended that all highly absorbent cementitious subfloor surfaces be primed with GS400 Floor & Wall Primer prior to the application of the adhesive. For other subfloor surfaces, please contact Roberts Australia.

All concrete substrate floors should be tested for moisture content, according to the above Australian Standard, prior to undertaking surface priming or installation of the floorcovering.

### Application

Roberts 95 Extra Tack Carpet Adhesive is to be applied using a long nap roller, or the following types of notched trowel.

2.4mm x 2.4mm x 2.4mm 'V' notched (Roberts 10-353 Switch blade) for laminated foam underlays and smooth backed carpets. Coverage up to 3m<sup>2</sup>/litre.

3.2mm x 1.6mm x 3.2mm 'V' notched (Roberts 10-354 Switch blade) for textured backed carpets. Coverage up to 2m<sup>2</sup>/litre

A strong tack develops rapidly enabling carpet/underlay to be lowered in almost immediately at temperatures in excess of 15 °C. In colder conditions, allow adhesive to remain open until tack and grab develop then lower in the carpet/underlay.

Check to ensure that the complete transfer of adhesive to the carpet/underlay has occurred. Roll the finished installation with a 25-35kg roller. Complete the installation according to floorcovering manufacturer's instructions. Do not allow heavy traffic for 24 hours.

### Clean Up

Clean tools immediately after use with warm soapy water. Dried adhesive may be softened and lifted with Roberts 550 Acrylic/Latex Adhesive Remover. Roberts 550 is not recommended for removing adhesive from vinyl, carpet or painted surfaces.

Do not thin adhesive.

### Typical Properties

Appearance	Off white
Base	Latex
Solids	Approx 62%
Viscosity	Trowellable/ Rollable
Shelf Life	Up to 1 year in sealed container at 20 °C
Freezability	Avoid freezing
Packaging	15 litre

### Safety & Handling

Material Safety Data Sheet available upon request.

Issued: July 2013

The application, use and processing of our products is the responsibility of the user. Any technical or other advice, information or data provided by us, whether verbally, in writing or by way of trials or tests, is given without guarantee or warranty. Refer to Material Safety Data Sheets for information on Storage & Handling, Health and Safety, and Transport.

### RLA POLYMERS PTY LTD

ACN 004 709 915

215 Colchester Road, Kilsyth, Victoria 3137 Australia  
P.O. Box 147, Kilsyth, Victoria 3137 Australia  
Telephone: (03) 9728 1644 • Facsimile: (03) 9728 6009

E-mail: info@rlapolymers.com.au • Web: www.rlapolymers.com.au

 A Vita Group Company



RLA 044B

67 Dalgety Drive (P.O. Box 97-575)  
Manukau City, Auckland, New Zealand  
Telephone: (9) 268 0301  
Facsimile: (9) 268 0305

